


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Model: 3RAWZ481EML2 (Pewter)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	9		Plug, Terminal	24	8316076	,
	8545902	Label,	10	94613	Terminal			Wrinkle Guard
		Wiring Diagram	11	3390647	Screw, 8-18 x 1/2	25	8522378	,
	8577079	Use & Care Guide	12	488886	Screw, 8-18 x 1/2	26	8562100	Switch,
	8563878	Installation	13	3980121	Button,			Push-To-Start
		Instructions			Push-To-Start	27	3399642	Switch,
	8315975	Installation	14	3979738	Bracket, Timer			Temperature
		& User Guide	15	3979743	Bracket,	28	8543291	Harness, Console
					Switch Mounting	29	3347243	Connector,
2	3980096	Тор	16	8281225	Screw, 8-18 x 1/2			6-Circuit
3		Harness, Main	17	8543319	Medallion	30	3397269	Connector, Timer
4		Panel, Console	18	3956540	Console, Center	31	3401144	Connector
-		(Includes	19	3400238	Screw, 2-28 x 1/2			(PTS Relay)
		Illus. 13, 14	20	3980205		32	692997	
		15, 17, 18 & 19)	21	3951198	Fuse	33	3980218	Knob,
5	3394427		22	3390646	Screw, 8-18 x 5/16			Timer Assembly
6		Bracket, Console	23	3980421		34	3980129	Knob, Control (2)
7		Connector, Sensor			(Timer)	35	3980339	Shield, Drip
8		Terminal			- /			, 1

CABINET PARTS




CABINET PARTS

For Model: 3RAWZ481EML2 (Pewter)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
			20			l —		
1	8317342	Cover, Terminal Block	21		Tri Ring Cover–Plate	38	3395535	Exhaust Pipe (Long)
2	98139	Screw, 8–32 x 5/16	22		Ramp, Door	39	3388674	Idler Bracket
3		Screw, 10-32 x 5/8	23		Dry Rack	41		Switch, Door
_		(Ground)			Support	42	3400934	
4	3397659	Block, Terminal	24		Panel, Side (R.H.)			6-20 x 1 1/16
5	8318457	Switch, Broken	25	8521950	Dry Rack	43		Screw, 8-18 x 1/2
		Belt			Assembly	44		Seal, Front Panel
6	8521947	Dry Rack	26		Restrainer, Belt	45		Screw, 10-16 x 1/2
		(Top)	27	3404470	Motor, Assembly	46		Clip, Toe Panel
7		Panel, Side (L.H.)		0.4005.40	50 HZ.	47		Wire, Ground
8		Foot, Dryer	29		Pulley 50 HZ.	50		Base, Cabinet
	279810	Foot – Optional	30 31		Belt, Drive	51		Front Panel
		(Extended Length	31	8541503	Stack Assembly	52		Strike, Door (2)
		Package Of 2)	32	2207110	Bracket, Motor	53	90767	Screw, 8–18 x 3/8
0	660659	(Not Included)	33		Terminal Block	56 61	2090005	Bracket, Control Toe, Panel
9 10		Clamp, Motor (2) Spring, Idler	33	219090	Screw Kit (For	62		Panel, Rear
11		Retainer, Idler			Terminal Block)	63		Nut, Push-In
12		Plug, Multivent	34	49026	4" – 90° Elbow	64		Screw, 10–24 x 3/8
13	3388672	Pulley Assembly	35	8316644		"	0400007	O010W, 10 24 X 0/0
14		Terminal, Brass			Strain Relief			
17	270010	& Tinned (3)	36	3395532	Exhaust Pipe	Ont	ional Pa	rts Not Included
		(Includes Illus. 33)			& Bracket	1 — Opt	- Ionar r a	
15	8066120	Lever, Snap	37	3395534	Exhaust Pipe			
		Switch			(Short)		-	Exhaust Kit
16	3394081	Wire, Belt Switch			, ,	(Fo	r Side &	Bottom Venting)
17		Sound Panel				l —		
18	233520	Washer, Thrust						
19	8543119	Wire, Jumper				66	279969	Grey
		(Includes						
		Illus. #41)	I			I		

BULKHEAD PARTS

For Model: 3RAWZ481EML2




BULKHEAD PARTS

For Model: 3RAWZ481EML2 (Pewter)

Illus.	Part		Illus.	Part		Illus.	Part	
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
1	3399508	Shaft, R.H. Thread	17	3387809	Bulkhead, Rear	37	697772	Wheel, Blower
2		Screw, 8-18 x 1/2	18	3387459	•	39	3394986	Spring, Lint
3	3394984	•	19	3399509				Screen Door
		Screen	20	690997		42	3387137	Thermistor
4	98139	Screw, 8-32 x 5/16	21		Roller, Support	44	8544362	Housing, Blower
5	697354	Air Duct Assembly	22		Exhaust Pipe	45	8066168	Lint Duct Assembly
6	697813	Seal, Outlet	23		Housing, Outlet	46	3392537	Heater Box
		Housing	24	8529007		47	3977394	Thermal Cut-Off
7	697814	Seal, Drum Front			Rear Bulkhead			(Includes
8	3359452	Nut,3/8 x 16(R.H.)	25	8543082	Complete Drum			Illus. 48)
9	8066086				Assembly	48	3390291	Thermostat 250°F
		Plug	26	97787	Screw, 11-16 x 3/4			(121°C)
10	696302	Shield, Exhaust	27	697694	Seal, Drum	50	8066099	
12	3388229	• *	28	695240	Screw, 8-18 x 1/2			Heater Box
		Pipe	29	90767	Screw, 8-18 x 3/8	51		Screw, 10-16 x 1
13	3390646	,	30	8519221	Channel Bracket,	53		Baffle, Drum
14					Rear Bulkhead (2)	54		Bulkhead, Front
15	279457	Terminal Wire	31	8519275		58		Grill, Outlet
		Kit (For Heater			Rear Bulkhead	59		Thermal Fuse
		Element Wiring	34	3357011	Screw, 10-16 x 1/2	60		Seal, Cover Plate
		Harness Repair)				64	8066170	Lint, Screen
16	3387709	Nut, 3/8–16 (L.H.)	l					

DOOR PARTS For Model: 3RAWZ481EML2 (Pewter)



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Plug, Strip	7		Handle, Door	11	355515	,
2	8505078	Door Hinge Assembly	8	3400224	1/4-20 x 1/2	12	3980213	8–18 x 11/16 Door, Outer
3	3980214	Cover, Door Hinge	9	8519374	Plug, Door Handle (2)	13 14	8545879	Window Door Catch
4 5		Screw, 8–18 x 5/8 Screw, 10–32 x 3/8	10	8557500	Door Assembly (Inner)	14	3303441	Assembly
		,			(Includes Illus. 14)			

OPTIONAL PARTS (NOT INCLUDED) For Model: 3RAWZ481EML2

For Model: 3RAWZ481EML2 (Pewter)

Illus. Part

No. No. DESCRIPTION

PAINT, TOUCH-UP (1/2oz.)

4396174 Pewter

PAINT, PRESSURIZED SPRAY (12 oz.)

4396175 Pewter 350938 Primer, Gray

ACCESSORY PARTS

8529894 Hold Down Kit